



(仅供科研使用，不得用于临床诊断!)

人谷胱甘肽(GSH)ELISA 试剂盒

使用说明书 规格：48T/96T

使用前请仔细阅读说明书。如果有任何问题，请通过以下方式联系我们：

官方热线：025-5229-8998 销售部电话：13914481711 技术电话：

15950492658 联系邮箱：3224949330@qq.com 公司网址：

www.byabscience.cn 具体保质期请见试剂盒外包装标签。请在保质期内使用试剂盒。

联系时请提供产品货号、生产日期（见盒签），以便我们更高效为您服务。



试剂盒性能 检测范围：100 ng/mL- 8
ng/mL。

灵敏度：最低检出剂量小于 0.1 ng/mL。

精密度：批内变异系数 CV% 小于 10%；批间变异系数 CV% 小于 15%。

回收率：回收率在 85%-115% 之间。

特异性：本试剂盒识别天然和重组人谷胱甘肽(GSH)，与结构类似物无交叉。

稳定性：2℃-8℃ 保存，有效期 6 个月。

用途：用于检测血清、血浆、细胞培养上清液和组织等样本中人谷胱甘肽(GSH)的浓度。

保质期：2℃-8℃ 保存，有效期 6 个月。

实验原理

试剂盒采用酶联免疫分析方法。采用生物素标记 GSH，纯化的抗 GSH 抗体包被微孔板，在竞争抑制反应中，一定量的固相抗体与生物素标记 GSH 及非标记抗原（校准品或标本）进行抑制竞争反应，抗体与生物素标记的 GSH 结合量受非标记抗原量所抑制，非标记抗原量多，抗体与生物素标记的 GSH 结合就少，反之结合就多；反应平衡后，形成固相抗体-生物素化 GSH，再加入酶标记的亲合素，形成固相抗体-生物素化 GSH-酶标-亲合素复合物。经加底物显色后，用酶标仪在 450nm 波长下测定吸光度（OD 值）。随着 GSH 浓度的升高，OD 值逐渐下降呈良好的线性关系。本试剂盒具有灵敏度高、特异性强、重复性好、操作简单、快速等特点，对血清中 GSH 的减少或升高有可靠的检出性能。

网址: www.byabscience.cn

Official hotline: 025-5229-8998

Supervision phone number:



Kit components and storage: Store unopened kits at 2-8

degrees Celsius. Do not use expired kits.

Components	48-well configuration	96-well configuration	Store after opening
Pre-coated enzyme plate	48T	96T	2-8°C 14 days
Standard product	0.3mL*6 tubes	0.3mL*6 tubes	2-8°C 14 days
sample diluent	3ml	6ml	2-8°C 180 days
biotinylated antigen	3ml	6ml	2-8°C 14 days
HRP labeled avidin	3ml	6ml	2-8°C 180 days
Chromogenic substrate A	3ml	6ml	2-8°C 180 days
Chromogenic substrate B	3ml	6ml	2-8°C 180 days
stop solution	3ml	6ml	2-8°C 180 days
20×Lotion	15ml	25ml	2-8°C 180 days
sealing film	2 sheets	2 sheets	
manual	1 serving	1 serving	
Ziplock bag	1	1	

The concentrations of calibrators are: 8, 800, 400, 200, 100, 0 ng/mL.

Note: 1: Before use, please check whether the label and quantity of

the reagents in the kit are consistent with the table.

2: If the components of the kit need to be used again, please ensure that they have

not been contaminated since the last use. 3: If the enzyme plate is not used up in a

single time, remember to seal it and store it at 2-8°C.

Prepare your own test equipment required for the test (not provided, but can assist in

1) Microplate reader capable of detecting absorbance at 450 nm 2) Pipette,

pipette tip, and sample addition tank 3) 37°C incubator or water bath 4) Test

tubes, centrifuge tubes, measuring cylinders, etc. for preparing reagents 5)

Distilled water or deionized water Ionized water

Nanjing BYabsience technology Co.,Ltd

Website: www.byabsience.cn

Official hotline: 025-5229-8998

Supervision phone number:



6) Vortex oscillator and microplate oscillator.

Notes: 1) For scientific research use only,
not for clinical diagnosis.

2) Use within the validity period marked on the kit. Expired products must not be used.

3) Do not mix with kits or components from other manufacturers. Use the sample diluent provided with the kit.

4) If the sample value is higher than the highest standard concentration value, please dilute the sample appropriately and then re-measure.

5) Human anti-mouse and other heterophilic antibodies present in the sample to be tested will interfere with the test results. Please eliminate this factor before testing.

6) The test results obtained by other methods are not directly comparable to the test results of this kit.

7) Please wear a lab coat and latex gloves for protection during the test. Especially when testing blood or other body fluid samples, please follow the national biological laboratory safety protection regulations.

8) Carry out incubation strictly according to the specified time and temperature to ensure accurate results. All reagents must reach room temperature 20-25°C before use. Store reagents refrigerated immediately after use.

9) Improper plate washing can lead to inaccurate results. Make sure to absorb as much liquid as possible from the wells before adding substrate. Do not allow the microwells to dry out during incubation.

10) Eliminate residual liquid and fingerprints on the bottom of the plate, otherwise it will affect the OD value.

11) The substrate chromogenic solution should be colorless or very light in color.

12) Avoid cross-contamination of reagents and specimens to avoid erroneous results.

- 13) Avoid direct exposure to strong light during storage and incubation.
- 14) The microplate reader used for detection needs to be equipped with a filter capable of detecting a wavelength of $450\pm 10\text{nm}$, and the optical density range is between 0-3.5. It is recommended to preheat 15 minutes in advance before use.
- 15) The EP tubes and tips used in the test are single-use and are strictly prohibited from mixing.

Nanjing BYabscience technology Co.,Ltd

Website: www.byabscience.cn

Official hotline: 025-5229-8998

Supervision phone number:



Sample preparation and storage

The following lists only general guidelines for sample collection and preservation. During the collection and storage of all samples, sodium azide must not be used as a preservative. If the sample is not analyzed immediately, it should be aliquoted and stored frozen, and repeated freezing and thawing should be avoided.

Cell culture supernatant - centrifuge to remove precipitate, analyze immediately or aliquot and store frozen at -20°C.

Serum - Collect blood in a clean test tube, coagulate at room temperature for 30 minutes, centrifuge at 2000×g for 20 minutes, and collect serum. Analyze immediately or aliquot and store frozen at -20°C.

Plasma—anticoagulate with heparin, citrate, or EDTA, and centrifuge at 2000×g for 20 minutes at 2-8°C within 30 minutes of blood draw. To eliminate the influence of platelets, it is recommended to further centrifuge at 10,000 × g for 10 minutes at 2-8°C. Analyze immediately or aliquot and store frozen at -20°C.

Cell lysis buffer - For adherent cells, remove the culture medium and wash with PBS, normal saline or serum-free culture medium. Add an appropriate amount of lysis solution and pipet several times with a gun to fully contact the lysate and cells. Typically after 10 seconds, cells are lysed. For suspended cells, collect the cells by centrifugation and wash them once with PBS, physiological saline or serum-free culture medium. Add an appropriate amount of lysis solution, blow the cells with a gun, and flick them with your fingers to fully lyse the cells. After full lysis, centrifuge at 10000-14000×g for 3-5 minutes and take the supernatant. Analyze immediately or aliquot and store frozen at -20°C.

Tissue homogenate - rinse the tissue with pre-cooled PBS (0.01M, pH=7.4) to remove residual blood (lysed red blood cells in the homogenate will affect the measurement results), weigh and cut the tissue into pieces. Mix the minced tissue with the corresponding volume of PBS (generally

according to the weight volume ratio of 1:9, for example, 1g of tissue sample corresponds to 9mL of PBS). The specific volume can be adjusted appropriately according to the experimental needs and recorded. It is recommended to add Protease inhibitor) was added to a glass homogenizer and ground thoroughly on ice. In order to further lyse tissue cells, the homogenate can be sonicated or repeatedly frozen and thawed. Finally, centrifuge the homogenate at $5000 \times g$ for 5 to 10 minutes, and take the supernatant for detection.

Urine - Collect in sterile tubes and centrifuge at $2000 \times g$ for 20 minutes. Carefully collect the supernatant. If a precipitate forms, centrifuge again.

Nanjing BYabscience technology Co.,Ltd

Website: www.byabscience.cn

Official hotline: 025-5229-8998

Supervision phone number:

**Reagent preparation 1. Before use, all components must be rewarmed**

for at least 60 minutes to ensure sufficient rewarming to room temperature.

2. Concentrated washing liquid: The concentrated washing liquid taken out from the refrigerator will produce crystals. This is a normal phenomenon. Heating in a water bath will completely dissolve the crystals. Concentrated detergent and distilled water, dilute 1:20, that is, 1 part of concentrated detergent, add 19 parts of distilled water.

Operating procedures: Return all reagents and components to room temperature first. It is recommended to do duplicate holes for standards, quality control materials and samples.

1. Prepare the working solution of various components of the kit according to the method described in the previous instructions.
2. Take out the required slats from the aluminum foil bag, seal the remaining slats in a ziplock bag and return it to the refrigerator.
3. Take out the pre-coated plate from the sealed bag, set up a blank control well without adding any liquid; set up 2 wells for each calibrator, and add 50 μ l of the corresponding calibrator to each well; add the serum to be tested directly to each of the remaining detection holes. Or 50 μ l of quality control product.
4. Add 50 μ l of biotinylated antigen to all wells except the blank well, mix well, attach sealing film, and incubate at 37°C for 60 minutes.
5. Manual plate washing: discard the liquid in the wells, fill each well with washing solution, let stand for 10 seconds and spin dry, repeat 3 times and pat dry. Wash the plate with a plate washer: select the washing program 3 times and pat dry after washing the plate.

(Tip: In order to obtain ideal experimental results, the residual liquid must be completely removed. After washing the plate, please proceed to the next step immediately and do not let the microplate dry.) 6. Add 50 µl of enzyme-labeled avidin to each well (blank (Excluding control wells), mix well, affix sealing film, and incubate at 37°C for 30 minutes.

7. Manual plate washing: discard the liquid in the wells, fill each well with washing solution, let stand for 10 seconds and spin dry, repeat 3 times and pat dry. Wash the plate with a plate washer: select the washing program 3 times and pat dry after washing the plate.

8. Add 50 µl of chromogen A and 50 µl of chromogen B to each well. After shaking and mixing, place at 37°C to develop color in the dark for 15 minutes. Add 50 µl of stop solution to each well.

9. Use a microplate reader to read, take the wavelength of 450nm, first use the blank control well to adjust the zero point, and then measure the optical density value (OD value) of each well.

Nanjing BYabscience technology Co.,Ltd

Website: www.byabscience.cn

Official hotline: 025-5229-8998

Supervision phone number:



Result calculation

9. Use the concentration of the standard substance as the abscissa and the corresponding absorbance (OD value) as the ordinate. Use computer software and four-parameter Logistic curve fitting (4-pl) to create a standard curve equation. Through the absorbance (OD value) of the sample value), use the equation to calculate the concentration value of the sample. [Calculation using ELISA Calc software]
10. If the sample is diluted, the concentration value measured by the above method must be multiplied by the dilution factor to obtain the final concentration of the sample. Note: Experimenters need to establish a standard curve based on their own experiments. For each test, a standard curve must be established for each enzyme plate. The following curves are for reference only!



(Schematic diagram of the music, for reference only)

Nanjing BYabscience technology Co.,Ltd

Website: www.byabscience.cn

Official hotline: 025-5229-8998

Supervision phone number:



[Problem Analysis] If the experimental results are not good, please take pictures of the color development results in time, save the experimental data, keep the used strips and unused reagents, and then contact our company's technical support to solve the problem for you. At the same time, you can also refer to the following information:

[Questions and Answers]

Problem description	Possible reasons	Corresponding countermeasures
standard curve gradient difference	Incorrect liquid aspiration or	Check pipettes and tips
	Equilibration time is too short	Ensure sufficient balancing time
	Incomplete washing	Ensure the washing time and number of washings and the amount of liquid added to each hole
Very weak or colorless	Incubation time too short	Ensure adequate incubation time
	The experimental temperature is incorrect	Use recommended experimental temperatures
	Insufficient reagent volume or missing addition	Check the liquid aspirating and adding process to ensure that all reagents are added in order and in
	Incorrect dilution	
	Enzyme label inactivation or substrate failure	Mix enzyme conjugate and substrate and check by rapid color development
Reading value is low	Microplate reader settings are incorrect	Check the wavelength and filter
		Turn on the microplate reader and preheat it in advance
Large coefficient of variation	Adding fluid incorrectly	Check the filling situation
High background value	The working concentration of the	Use the recommended dilution
	Incomplete washing of enzyme plate	Ensure that each step of cleaning is complete; if using an automatic plate washer, please check whether all outlets are blocked;
	The lotion is contaminated	Prepare fresh lotion
Low sensitivity	Improper storage of ELISA kits	Store relevant reagents according to
	Not terminated before reading	Stop solution should be added to

Nanjing BYabscience technology Co.,Ltd

Website: www.byabscience.cn

Official hotline: 025-5229-8998

Supervision phone number: